

EWING FLAGPOLE AND TRAFFIC PRODUCTS CO. INC.

1445 HOPKINS STREET, WHITBY, ONTARIO L1N 2C2

TEL: 905-666-5600

FAX: 905-666-5646

Maintenance for Flagpoles

Just as with any other operable equipment, flagpoles must be properly cared for if they are to perform satisfactorily over a period of years. The maintenance of modern flagpoles consists principally of preserving the finish of the pole shaft, replacing the halyards if and when necessary, and properly caring for, and perhaps replacing, certain fittings that are subject to wear. Compared to the older wood and steel poles, the amount of maintenance needed is generally small.

Pole Shafts:

The maintenance required to preserve the shaft finish depends upon which metal the pole is made of, the type of finish used, and the conditions of the environment in which the pole is located.

Aluminum:

Aluminum poles may have mechanical finish, an anodized finish or an applied organic coating. Whatever the finish, little or no maintenance will normally be required because rainfall in most areas will remove dirt and soil that may be deposited on surface. However, should a build-up of dirt and soil occur, washing the surface with a mild detergent is advised. This is the only maintenance ever required for architectural class 1 anodized finish or for high performance, thermally cured, organic coatings. In the case of the satin brushed mechanical finish, if the surface appearance becomes objectionably discoloured by contaminants, the finish may be restored by the use of special cleaning agents.

Steel:

Steel flagpoles are finished with some type of applied coating, therefore most of them sooner or later require refinishing. The life of the coating depends on the pre-coating preparation of the metal, the type of coating used, and the atmospheric conditions to which it is exposed. Coating life expectancy ranges from 2 or 3 years for ordinary field applied paints to perhaps 20 years or more for the sometimes specified thermally cured high performance coatings. For the conventional painted finishes periodic maintenance should be provided whenever the paint becomes dingy or rust spots appear. Rust and loose paint should be removed, bare spots primed and a new coating applied. For installation in seacoast locations or corrosive industrial atmospheres, the rust resistance of steel can be greatly increased if the pole is hot dip galvanized before painting.

Bronze:

Most bronze poles have a lacquered statuary bronze finish. Over a period of several years, the length of time depending on atmospheric conditions, the lacquer coating gradually erodes and oxidation causes the surface colour to darken. Thereafter a natural patina develops. If such a patina is the desired effect (and often is) then little or no maintenance is required. However, if it is desired to prevent the development of the patina periodic maintenance is essential, and this involves a yearly oiling with a mixture of lemon oil and high grade paraffin oil. In rare instances it may be desired to restore the original finish. This can be done by stripping down to bare metal and applying a new chemical finish.

Stainless Steel:

Stainless steel poles require little or no care to maintain their finish indefinitely. For aesthetic reasons only, occasional washing may be desirable in some locations, but otherwise they are maintenance free.

Halyards:

Conventional external halyards should be checked every three months for signs of wear and need for replacement. The cost of replacement can be minimized if they are replaced when wear first becomes apparent, before a break occurs. This can be accomplished without climbing the pole. Simply butt the end of the new rope to one end of the old rope and thread a fine wire through both, at about 1" from their ends, then tightly wrap the wire around the rope over the 2" tape. Finally carefully hoist the joined ropes up the pole, over the sheave and down to the starting position.

When replacement becomes necessary it should be recognized that although manila and cotton ropes have given good service over the years, the modern synthetic ropes are far superior. Braided polypropylene and nylon are generally recommended as the best halyard materials, because of their strength, mildew and rot resistance and exceptional wearing qualities.

External Fittings:

The amount of maintenance care required for flagpole fittings depends upon the type of halyard system provided.

On conventional external halyards about the only items that should be checked periodically are the flag attachment devices on the halyard. If these become damaged or cease to function properly they should be replaced. Truck assemblies are designed to be maintenance free and other items such as finials, cleats, cleat cover boxes and halyard protectors require no attention, either, under normal circumstances.

Internal Fittings:

For internal halyard systems, periodic inspection and maintenance of certain parts is essential, to insure trouble-free operation. It is recommended that the winch shaft and dog be lubricated at monthly intervals and the following items be checked for wear at the same time:

- halyard cable (check for kinks or frays)
- Cable fittings, including flag attachments
- Plastic chain (check for weak or warped links)
- Weighted loop and attachments
- Lubricate winch - every 4 months
- Access door lock – lubricate every 4 months
- Mounting bolts (check for tightness)

The cable should be replaced if found to be kinked or frayed. Other parts, (i.e. cable clamps, shackles, flag attachments, winch and lock) should of course be lubricated/replaced when found to have excessive wear or are not functioning properly.

Precautions:

Halyard rope, regardless of type, should never be used as a means of hoisting a person aloft. Only a qualified workman with proper equipment should be allowed to climb a flagpole.

A locked cleat cover insures against tampering with the halyard at the cleat, but does not prevent vandals from cutting the rope above the box (or even above a halyard protector.) Do not use sash chain or wire rope to prevent such vandalism because they will damage the shaft of the pole.

The beating of metal flag snaps against the pole shaft, when the flag is not attached, tends to damage the shaft finish. When the flag is removed, wrap the halyard around the pole in a few long spiral turns, to prevent the noise made by the wind whipping the halyard against the pole, and position the flag snaps near or on the cleat.